




Model **1962**

Revision 3.1 Updated Sept 18, 2012

# Technical Manual & Parts Lists



From the library of: Diamond Needle Corp

**Atlanta Attachment Company**

362 Industrial Park Drive

Lawrenceville, GA 30046

770-963-7369 • [www.atlatt.com](http://www.atlatt.com)



# ATLANTA ATTACHMENT COMPANY, INC.

## Confidential and Proprietary Information

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.

All materials contained herein are additionally protected by United States Copyright law and may not be used, disclosed, reproduced, distributed, published or sold without the express written consent of Atlanta Attachment Company, which consent may be withheld in Atlanta Attachment Company's sole discretion. You may not alter or remove any copyright, trademark or other notice from copies of these materials.

## Patents & Patents Pending

The sale of this product does not sell or otherwise transfer any license or other rights under any U.S. Patent or other corresponding foreign patent.

This equipment is manufactured under one or more of the following patents:

4,280,421 • 4,432,294 • 4,466,367 • 4,644,883 • 5,134,947 • 5,159,889 • 5,203,270 • 5,373,798 • 5,437,238 • 5,522,332 • 5,524,563 • 5,562,060 • 5,634,418 • 5,647,293 • 5,657,711 • 5,743,202 • 5,865,135 • 5,899,159 • 5,915,319 • 5,918,560 • 5,924,376 • 5,979,345 • 6,035,794 • 6,055,921 • 6,202,579 • 6,279,869 • 6,295,481 • 6,494,225 • 6,523,488 • 6,574,815 • 6,802,271 • 6,834,603 • 6,968,794 • 6,994,043 • 7,543,364 • 7,574,788 • 7,647,876 • 7,735,439

Foreign Patents: 9-520,472 • 0,537,323 • 92,905,522.6 • 96,936,922.2 • 2,076,379 • 2,084,055  
Other U.S. and Foreign Patents Pending.

## IMPORTANT

**It is important to read and understand the information contained within this manual before attempting to operate the machine. Atlanta Attachment Co., Inc. shall not be held liable for damage resulting from misuse of the information presented within, and reserves the right to change the information contained within, without prior notification.**

# Contents

Important Safety Instruction .....	1
Liability .....	2
Safety Equipment on the Machines .....	3
Protective Eyewear .....	4
Important Notices.....	5
Maintenance .....	7
Repair .....	8
A Word to the End User.....	9
Safety Precautions.....	10
Features .....	11
General Machine Data .....	11
Operating Procedure .....	11
Adjustments / Controls .....	12
Control Box Functions.....	13
Border Splicing Methods .....	14
Thread Sensor Instructions .....	15
Clutch-Brake Installation & Maintenance .....	16
Airline Connections .....	17
Lubrication.....	17
Parts Replacement.....	18
Troubleshooting .....	20
Electric Eye Sensor Adjustment .....	21
General Machine Maintenance .....	21
Recommended Spare Parts List .....	23
1962-LPAR4 Parameter Settings.....	24
1962-PPAR4 Parameter Settings .....	25
1962-RPAR4 Parameter Settings.....	26
Assembly Drawings & Parts Lists .....	28
11962EG24EH Auto Border Sew, O&U Head.....	30
1961-500F Sewing Head Assembly.....	31
1961-800E Waste Assembly.....	32
1961-KIT10 Border Splicing Assembly .....	33
1962-210A Tension Rack Assembly, 36” .....	34
1962-001E Main Assembly, O/U, 36” Cap .....	36
1961-300GB Puller Assembly, 36” Worm Gear .....	38
1961-900D Control Box .....	40

---

---

1962-320G Prefeed & Rewind Assembly.....	42
26238 Leg Sub-Assembly.....	43
1962-330G Generic Clutch Assembly .....	44
1962-350E Rear Roller Assembly, 38” .....	45
33008708 Ball Bearing Disc Assembly.....	46
1961PD1 Pneumatic Diagram.....	47
1961-900WD3 Wiring Diagram .....	48

## Important Safety Instruction



This part of the Instruction Material is provided for the safe use of your equipment. It contains important information to help work safely with the unit and describes the dangers inherent in machinery. Some of these dangers are obvious, while others are less evident.

### Mandatory Information

All persons operating and/or working on the 1962 should read and understand all parts of the Safety Instructions. This applies, in particular, for persons who only operate and/or work on the unit occasionally (e.g. for maintenance and repair). Persons who have difficulty reading must receive particularly thorough instruction.

### Scope of the Instruction Material

- The Instruction Material comprises:
- Safety information
- Operator Instructions
- Electrical and Pneumatic diagrams

And may also include;

- A list of recommended spare parts
- Instruction Manual(s) for components made by other manufacturers
- The layout and installation diagram containing information for installation

### Intended Use

Our machines are designed and built in line with the state of the art and the accepted safety rules. However, all machines may endanger the life and limb of their users and/or third parties and be damaged or cause damage to other property, particularly if they are operated incorrectly or used for purposes other than those specified in the Instruction Manual.

### Exclusion of Misuse



Non-conforming uses include, for example, using the equipment for something other than it was designed for, as well as operation without duly installed safety equipment. The risk rests exclusively with the end user.

Conforming use of the machine includes compliance with the technical data, information and regulations in all parts of the complete Instruction Material, as well as compliance with the maintenance regulations. All local safety and accident prevention regulations must also be observed.

## Liability

The machine should only be operated when in perfect working order, with due regard for safety and the potential dangers, as well as in accordance with the Instruction Material. Faults and malfunctions capable of impairing safety should be remedied immediately. We cannot accept any liability for personal injury or property damage due to operator errors or non-compliance with the safety instructions contained in this booklet. The risk rests exclusively with the end user.

The Instruction Material should always be kept near the machine so that it is accessible to all concerned.

The local, general, statutory and other binding regulations on accident prevention and environmental protection must also be observed in addition to the Instruction Material. The operating staff must be instructed accordingly. This obligation also includes the handling of dangerous substances and provision/use of personal protective equipment.

The Instruction Material should be supplemented by instructions, including supervisory and notification duties with due regard for special operational features, such as the organization of work, work sequences, the personnel deployed, etc.

The personnel's awareness of the dangers and compliance with the safety regulations should be checked at irregular intervals.

## Choice and Qualification of Personnel

Ensure that work on the machine is only carried out by reliable persons who have been appropriately trained for such work - either within the company, by our field staff or at our office - and who have not only been duly appointed and authorized, but are also fully familiar with the local regulations. Work on the machine should only be carried out by skilled personnel, under the management and supervision of a duly qualified engineer.

This not only applies when the machine is used for production, but also for special work associated with its operation (start-up and maintenance), especially when it concerns work on the hydraulic or electrical systems, as well as on the software/serial bus system.

## Training

Everyone working on or with the machine should be duly trained and informed with regard to correct use of the safety equipment, the foreseeable dangers which may arise during operation of the machine and the safety precautions to be taken. In addition, the personnel should be instructed to check all safety mechanisms at regular intervals.

## Responsibilities

Clearly define exactly who is responsible for operating, setting-up, servicing and repairing the machine. Define the responsibilities of the machine operator and authorize him to refuse any instructions by third parties if they run contrary to the machine's safety. This applies in particular for the operators of machines linked to other equipment. Persons receiving training of any kind may only work on or with the machine under the constant supervision of an experienced operator. Note the minimum age limits permitted by law.

## A Word to the Operator

The greatest danger inherent in our machines: is that of fingers, hands or loose clothing being drawn into a machine by live, coasting or rotating tools or assemblies or of being cut by sharp tools or burned by hot elements.

### **ALWAYS BE CONSCIOUS OF THESE DANGERS!**

## Safety Equipment on the Machines



All machines are delivered with safety equipment, which shall not be removed or bypassed during operation.

The correct functioning of safety equipment on machines and systems should be checked every day and before every new shift starts, after maintenance and repair work, when starting up for the first time and when restarting (e.g. after prolonged shutdowns).

If safety equipment has to be dismantled for setting-up, maintenance or repair work, such safety equipment shall be replaced and checked immediately upon completing the maintenance or repair work. All protective mechanisms shall be fitted and fully operational whenever the machine is at a standstill or if it has been shut down for a longer period of time.

## Damage

If any changes capable of impairing safety are observed in the machine or its mode of operation, such as malfunctions, faults or changes in the machine or tools, appropriate steps must be taken immediately, the machine switched off and a proper lockout tagout procedure followed. The machine should be examined for obvious damage and defects at least once per shift. Damage found shall be immediately remedied by a duly authorized person before resuming operation of machine.

The machine should only be operated when in perfect working order and when all protective mechanisms and safety equipment, such as detachable protective mechanisms, emergency STOP systems, etc. are in place and operational.

## Faults or Errors

The machine must be switched off and all moving or rotating parts allowed to come to a standstill and secured against accidental restart before starting to remedy any faults or errors.

## Signs on the Machine


Safety and danger signs on the machine should be observed and checked at regular intervals to ensure that they are complete and undamaged. They should be clearly visible and legible at all times.

### Clothing, Jewelry, Protective Equipment

Long loose hair, loose-fitting clothes, gloves and jewelry, including rings, should be avoided in order to avoid injuries due to being caught, drawn in and wound up inside the machine.



## Protective Eyewear



Protective eyewear that has been tested by the local authorities should be worn whenever there is a possibility of loose or flying objects or particles such as when cleaning the machine with compressed air.

## Tools

Always count the number of tools in your possession before starting work on the machine. This will allow you to check that no tools have been left behind inside the machine. Never leave a tool in the machine while working.

## Oils, Lubricants, Chemicals

Note the applicable safety regulations for the product used.

## No Smoking, Fire, Explosion Hazard

Smoking and open flame (e.g. welding work) should be prohibited in the production area due to the risk of fire and explosions.

## Workplace

A clear working area without any obstructions whatsoever is essential for safe operation of the machine. The floor should be level and clean, without any waste.

The workplace should be well lit, either by the general lighting or by local lights.

## Emergency STOP

The emergency STOP buttons bring all machine movements to a standstill. Make sure you know exactly where they are located and how they work. Try them out. Always ensure easy access to the nearest emergency STOP button while working on the machine.

## First Aid

1. Keep calm even when injured.
2. Clear the operator from the danger zone. The decision of what to do and whether to seek additional assistance rests entirely with you, particularly if someone has been trapped.
3. Give First Aid. Special courses are offered by such organizations as the employers' liability insurance association. Your colleagues should be able to rely on you and vice versa.
4. Call an ambulance. Do you know the telephone numbers for the ambulance service, police and fire service?

## Important Notices

### Reporting and Fighting Fires

Read the instructions posted in the factory with regard to reporting fires and the emergency exits. Make sure you know exactly where the fire extinguishers and sprinkler systems are located and how they are operated. Pass on the corresponding information to the firemen when they arrive. Ensure there are enough signs to avoid fire hazards.

The following fire extinguishers may be used:

- Dry powder extinguishers, ABC fire-extinguishing powder.
- Carbon dioxide fire extinguishers to DIN 14461 for electronic components. Great care must be exercised when using carbon dioxide fire extinguishers in confined, badly ventilated rooms (see DIN 14406 and 14270).

Isolate the machine from the power supply if a fire breaks out. Do not use water on burning electrical parts until it is absolutely certain that they have been completely disconnected from the power supply. Burning oils, lubricants, plastics and coatings on the machine can give off gases and vapors that may be harmful to your health.

A qualified person should be consulted to repair the damage after a fire.

### Electrical Power Supply



Before undertaking any maintenance or repair work on the machine, switch off the electrical power to the machine at the main source and secure it with a padlock so that it cannot be switched on again without authorization.

In practice, this may mean that the technician, electrician and operator all attach their own padlock to the master switch simultaneously so that they can carry out their work safely. Locking extension plates should be available for multiple locks if required. The primary purpose for a lockout/tagout procedure is to protect workers from injury caused by unexpected energizing or start-up of equipment.

Energy sources (electrical/pneumatic/hydraulic, etc.) for the equipment shall be turned off or disconnected and the switches locked or labeled with a warning tag. It is the responsibility of the employer to establish control procedures. Follow lockout/tagout procedures before, setup and/or any service or maintenance work is performed, including lubrication, cleaning or clearance of jams.

**Caution: The machine is still not completely de-energized even when the master switch is off.**

- Electricity - The machine is always isolated from the electrical power supply whenever the master switch has been switched off. However, this does not apply for the power supply in the control cabinet, nor for equipment that does not draw its power via the master switch.
- Pneumatic / hydraulic energy - Almost all our machines carry compressed air. In addition to switching off the master switch, the air supply must also be disconnected and the machine checked to ensure it is depressurized before starting any work on the machine; otherwise the machine may execute uncontrolled movements.

- Kinetic energy - Note that some motors or spindles, for example, may continue to run or coast run on after being switched off.
- Potential energy - Individual assemblies may need to be secured if necessary for repair work.

## Delivery of the Machine/Packaging

Note any markings on the packaging, such as weights, lifting points and special information. Avoid temperature fluctuations. Condensation may damage the machine.

## Transport Damage

The packaging and machine must immediately be examined for signs of damage in transit. Such damage must be reported to the shipper/transporter within the applicable time limits. Contact Atlanta Attachment Company and/or your transport insurer immediately, if signs of damage are visible. Never operate a damaged machine.

## Interim Storage

If the machine has to be stored temporarily, it must be oiled or greased and stored in a dry place where it is protected from the weather in order to avoid damage. A corrosion-inhibiting coating should be applied if the machine has to be stored for a longer period of time and additional precautions taken to avoid corrosion.

## Transporting the Machine

Disconnect the machine from all external connections and secure any loose assemblies or parts. Never step under a suspended load. When transporting the machine or assemblies in a crate, ensure that the ropes or arms of a forklift truck are positioned as close to the edge of the crate as possible. The center of gravity is not necessarily in the middle of the crate. Note the accident prevention regulations, safety instructions and local regulations governing transport of the machine and its assemblies.

Only use suitable transport vehicles, hoisting gear and load suspension devices that are in perfect working order and of adequate carrying capacity. Transport should only be entrusted to duly qualified personnel.

Never allow the straps to rest against the machine enclosure and never push or pull sensitive parts of the machine. Ensure that the load is always properly secured. Before or immediately after loading the machine, secure it properly and affix corresponding warnings.

All transport guards and lifting devices must be removed before the machine is started up again. Any parts that are to be removed for transport must be carefully refitted and secured before the machine is started up again.

## Workplace Environment

Our machines are designed for use in enclosed rooms: Permissible ambient temperature approx. 5 - 40 °C (40 - 104 °F). Malfunctions of the control systems and uncontrolled machine movements may occur at temperatures outside this range.

Protect against climatic influences, such as electrostatic charges, lightning strikes, hail, storm damage, high humidity, salinity of the air in coastal regions.

Protect against influences from the surroundings: no structure-borne vibrations, no grinding dust, or chemical vapors.

Protect against unauthorized access.

Ensure that the machine and accessories are set up in a stable position.

Ensure easy access for operation and maintenance (Instruction Manual and layout diagram); also verify that the floor is strong enough to carry the weight of the machine.

## Local Regulations

Particular attention must be paid to local and statutory regulations, etc. when installing machines and the plant (e.g. with regard to the specified escape routes). Note the safety zones in relation to adjacent machines.

# Maintenance

## General Safety Instructions

The machine shall be switched off, come to a standstill and be secured so that it cannot be switched on again inadvertently before starting any maintenance work whatsoever. Use proper lockout/tagout procedures to secure the machine against inadvertent startup.

Remove any oil, grease, dirt and waste from the machine, particularly from the connections and screws, when starting the maintenance and/or repair work. Do not use any corrosive-cleaning agents. Use lint-free rags.

Retighten all screw connections that have to be loosened for the maintenance and repair work. Any safety mechanisms that have to be dismantled for setting-up, maintenance or repair purposes must be refitted and checked immediately after completing the work.

## Maintenance, Care, Adjustment

The activities and intervals specified in the Instruction Manual for carrying out adjustments, maintenance and inspections must be observed and parts replaced as specified.

All hydraulic and pneumatic lines should be examined for leaks, loose connections, rubbing and damage whenever the machine is serviced. Any defects found must be remedied immediately.

## Waste, Disassembly, Disposal

Waste products should be cleared from the machine as soon as possible as not to create a fire hazard. Ensure that fuels and operating lubricants, as well as replacement parts are disposed of in a safe and ecologically acceptable manner. Note the local regulations on pollution control.

When scrapping (disassembling) the machine and its assemblies, ensure that these materials are disposed of safely. Either commission a specialist company familiar with the local regulations or note the local regulations when disposing of these materials yourself. Materials should be sorted properly.

# Repair

## Replacement Parts

We cannot accept any liability whatsoever for damage due to the use of parts made by other manufacturers or due to unqualified repair or modification of the machine.

## Repair, Electrical

The power supply must be switched off (master switch off) and secured so that it cannot be switched on again inadvertently before starting any work on live parts.

Those parts of the machine and plant on which inspection, maintenance or repair work is to be carried out must be isolated from the power supply, if specified. The isolated parts must first be checked to determine that they are truly de-energized before being grounded and short-circuited. Adjacent live parts must also be isolated.

The protective measures implemented (e.g. grounding resistance) must be tested before restarting the machine after all assembly or repair work on electric parts.

Signal generators (limit switches) and other electrical parts on the safety mechanisms must not be removed or bypassed. Only use original fuses or circuit overloads with the specified current rating. The machine must be switched off immediately if a fault develops in the electrical power supply.

The electrical equipment of our machines must be checked at regular intervals and any defects found must be remedied immediately.

If it is necessary to carry out work on live parts, a second person should be on hand to operate the emergency OFF switch or master switch with voltage release in the event of an emergency. The working area should be cordoned off and marked by a warning sign. Only use electrically insulated tools.

## Ventilation/Hazardous Gases

It is the end users responsibility to ensure adequate ventilation is provided to exhaust any and all noxious or hazardous gases that may be present in the working environment.

## Hydraulic and Pneumatic Systems

Work on hydraulic or pneumatic equipment shall only be carried out by persons with training, knowledge and experience of hydraulic systems. Pressure lines shall be depressurized before starting any repair work.

## General Liability

Liability for machine damage and personal injury is extinguished completely if any unauthorized conversions or modifications are undertaken. The machine must not be modified, enlarged or converted in any way capable of affecting safety without the manufacturer's prior approval.

## Starting Machine Movements

Read the Instruction Manual carefully to establish which keys and functions start machine movements.

## A Word to the End User

The end user has sole responsibility to enforce the use of safety procedures and guards on the machine. Any other safety devices or procedures due to local regulations should be should be retrofitted in accordance to these regulations and/or the EC Directive on the safety of machines.

Operator's position must always be readily accessible. Escape routes must always be kept clear and safety areas should be identified.

## Safety Precautions

Safety should be a constant concern for everyone. Always be careful when working with this equipment. While normal safety precautions were taken in the design and manufacture of this equipment, there are some potential safety hazards.






**Everyone involved with the operation and maintenance of this equipment should read and follow the instructions in this manual.**

**Operate the equipment only as stated in this manual. Incorrect use could cause damage to the equipment or personal injury.**

**It is the owner's responsibility to make certain that the operator reads and understands this manual before operating this equipment. It is also the owner's responsibility to make certain that the operator is a qualified and physically able individual, properly trained in the operation of this equipment.**

Specific safety warning decals are located on the equipment near the immediate areas of potential hazards. These decals should not be removed or obliterated. Replace them if they become non-readable.

- ALWAYS keep safety shields and covers in place, except for servicing.
- ALWAYS operate equipment in daylight or with adequate working lights.
- Follow daily and weekly checklists, making sure hoses are tightly secured and bolts are tightened.
- ALWAYS watch and avoid holes or deep depressions.
- ALWAYS wear adequate eye protection when servicing the hydraulic system and battery.
- NEVER operate a poorly maintained machine.
- NEVER allow persons to operate this machine without proper instruction.
- NEVER put hands or feet under any part of the machine while it is running.
- NEVER attempt to make any adjustments or repairs to the machine while running. Repairs or maintenance should be performed by trained personnel only.
- NEVER work under the machine unless it is safely supported with stands, blocks or a hoist and blocks.
- NEVER touch hot parts of machine.

	General Information (Read)
	Hazard warning sign: Electrical hazard, electrical hazard
	Hazard warning sign: Beware of damage to hands.
	Hazard warning sign: General Hazard
	General Information Symbol

The 1961 unit is an automatic workstation for serging both sides of a band of rolled or festooned material. This unit incorporates a variable torque winder on the rear of the machine to roll the material after surging.

## Features

- Automatically surges both edges of a band of material and winds onto a roll
- 125 feet of material sewn per minute
- Electrical lock out / tag out capability
- Variable speed puller with urethane rollers
- Electronic thread break detection
- Clutch motor driven left and right sergers.
- Turn off left head for single edge serging
- Foot pedal operation for manual sewing
- Variable torque winding
- Stops automatically when material runs out
- Adjustable tensioning of material as it is fed into the system
- Material capacity from 5" to 15" in width.

## General Machine Data

Electrical:	220 VAC, 10A, 50/60 Hz Single Phase
Pneumatic:	70-80 PSI, 14 SCFM avg.
Sew Head (RH):	Pegasus EX5203-M0C3-333-W5
Sew Head (LH):	Pegasus E52L-130/503-353W5
Needle:	SNB27140
Stitch Density:	4 SPI
Speed:	6000 RPM
Weight:	Approx. 1500 lbs.
Dimensions:	4' x 11'

## Operating Procedure

- Load roll of fabric onto roll rod in front of machine.
- Using the Left Head Adjustment Crank, set the Left head to the desired finished width.
- Feed fabric through guide assembly: over first bar, under second.
- Turn on Machine power. Turn off the left sewing head.
- Place the leading edge of the fabric under the foot of the right sewing head. Turn the head over by hand and check for interference problems and make sure machine is forming a stitch.
- Using the foot pedal, run the right head and gently pull the fabric until the leading edge of the fabric is at the foot of the left head.
- Place the leading edge of the fabric under the foot of the left sewing head. Turn the head over by hand and check for interference problems and make sure machine is forming a stitch.
- Turn on the left head. Power should now be on to both heads.
- Using the feed roller switch, lift the feed roller.
- Using the foot pedal, run both heads and gently pull the fabric until the leading edge of the fabric is between the feed rollers.
- Lower the feed roller.
- Using the foot pedal run about five to six feet of fabric through the machine.
- Place the fabric through the rods that form the winding mandrel.




- Press the Start button until the Sensor LED goes dark. The machine is now sewing in automatic mode.
- When all the fabric has been sewn the fabric sensor will stop the machine.
- Load a new roll of fabric onto the roll rod.
- Using the stapler provided in the spare parts kit, staple the leading edge of the new roll to the trailing edge of the previous roll.
- Using the foot pedal run the new fabric through the machine and around the winder. (If necessary, adjust the position of the left head)



(Note: Better size transitions between rolls will be achieved if the left sew head is run with the foot pedal while being moved in/out with the adjustment crank.)

- Cut the two rolls apart, remove the previous roll, and load the leading edge of the new roll through the rods that form the winding mandrel.
- (Repeat)



## Adjustments / Controls

- **Control Box (front)-** The front of the control box allows the operator to start and stop the automatic function of the machine, shut off power to the machine in the event of an emergency, view the hours of run time on the sewing heads, turn off power to the left sewing head, and to raise and lower the upper puller roller.
- **Control Box (rear)-** The rear of the control box allows the operator to turn the power on and off.
- **Left Head Adjustment Crank-** The left head adjustment crank is located on the left side of the machine. It allows the operator to move the Left head to sew various widths of fabric ranging from 0 to 18 inches wide.
- **Feed Speed Adjustment Thumbwheels-** The feed roller speed adjustment thumbwheels are located on the front of the step motor control box located behind the left door of the machine. It allows the operator to vary the speed of the feed roller. Increasing the speed of the feed roller causes fewer stitches per inch of sewing; likewise decreasing the speed of the feed roller causes more stitches per inch of sewing.
- **Winder Clutch Regulator-** The winder clutch regulator is located on the left side of the machine, behind the door. There are two regulators behind the door; the winder clutch regulator is the one on the top. The winder clutch regulator controls the amount of winding tension used to wind the fabric after being sewn. Increasing the air pressure supplied by the winder clutch regulator results in a more tightly wound roll of fabric.

# Control Box Functions

## Front of Control Box

(See Figure 1)

**1. Emergency Stop Button-** Pressing this button will turn off power to the machine. This button will lock when pressed. Twisting the button will cause it to unlock and return to its normal position. **WARNING!!** Unlocking the button with the Power On (Button 2, Figure 1) engaged will turn on power to the machine.

**2. Power On Button-** This button turns on power to the machine but the contactor is not engaged. This allows the operator to use the needle light without fear of the sewing heads running.

**3. Power Off Button-** This button turns off power to the machine and causes all functioning of the machine to stop.

**4. Sensor LED-** This LED is on when the contactor is engaged and the machine is ready for automatic operation.


**5. Start Button-** This button, pressed once, causes the contactor to engage the Sensor LED (4) to light. When this button is pressed again and held until the LED goes off, the automatic cycle is started.

**6. Stop Button-** This button causes the automatic cycle to stop.

**7. Left Head Off LED-** This LED is on only when the left head is off.

**8. Head Timer-** This timer shows how much actual run time (hours) there is on the heads (this timer only runs when the heads are sewing).

Figure 1



## Rear of Control Box


(See Figure 2)

**1. Left Head Switch-** Turns the power on/off to the left head.


**2. Feed Roller Switch-** Positions the Feed Roller up/down. Feed Rollers must be down during operation.

**3. (Optional) Rewind Motor Switch-** Reverses the direction of the rewind motor.

Figure 2



# Border Splicing Methods





**Note: The above illustration shows the two acceptable methods of border splicing for proper operation.**

# Thread Sensor Instructions

**INSTALL THREAD STANDS AS SHOWN. NOTE L HEAD THREAD DETECTOR BRACKET HAS BENT TAB FACING UP.**

**INSTALL DETECTORS AND PLUG IN SENSOR WIRE TO THE BOTTOM OF THE SENSOR THROUGH SLOT IN BRACKET.**




# Clutch-Brake Installation & Maintenance



## Installation


### Sheave and Pilot Mounting (See Figure 1)

- 1) Insert the Key (Item 21) into the keyway of the mounting shaft.
- 2) Slide the BW Clutch onto the mounting shaft until the Key (Item 21) is seated in the BW Clutch.
- 3) Insert and tighten the two set screws (Item 20).




### Coupling Mounting (See Figure 2)

- 1) Insert the Key (Item 21) into the keyway of the mounting shaft.
- 2) Slide the Pilot Mount BW Clutch onto the mounting shaft until the Key (Item 21) is seated in the Pilot Mount BW Clutch.
- 3) Insert and tighten the two set screws (Item 20).
- 4) Insert the customer supplied key into the coupling shaft.
- 5) Slide the Coupling Adapter onto the coupling shaft.
- 6) Using the cap screws provided with the Coupling Adapter, secure the Coupling Adapter to the Pilot Mount BW Clutch.
- 7) Insert and tighten the set screws provided with the Coupling Adapter.



### Brake Mounting (See Figure 3)

- 1) Using the cap screws provided with the Brake Adapter, secure the Brake Adapter to the Pilot Mount BW Clutch.
- 2) Insert the Key (Item 21) into the keyway of the mounting shaft.
- 3) Slide the Pilot Mount BW Clutch with the Brake Adapter onto the mounting shaft and key.
- 4) Align the notch in the Brake Adapter with a torque pin or stop on the machine.
- 5) Insert and tighten the two set screws (Item 20).



From the library of: Diamond Needle Corp

## Airline Connections

**See Figure 4 on page 19 for all references on this page**

A 1/8 NPT female air inlet fitting is provided in the piston (Item [13](#)) for the airline connection. The Air Hose Assembly (Item [19](#)) must be used so that no side forces are introduced to the air chamber-piston assembly.

Bearing drag on the hose during operation may be relieved by securing the hose to a support.



**Caution: The use of rigid pipe or tubing when connected directly to the BW Clutch will prevent proper actuation of the BW Clutch.**

### Lubrication

Nexen BW Clutches are factory lubricated and ready to install. The thrust bearings (Item [8](#)) are packed with a lubricant specially selected for the BW Clutch. If it becomes necessary to lubricate the thrust bearings, use Nexen H-130 (Product No. 853900). Frequency of lubrication of the thrust bearings will depend on the speed of operation, temperature, and severity of application. The radial bearing (Item [3](#)) is pre-lubricated, sealed, and requires no further lubrication. To disassemble the BW Clutch for lubrication, refer to Parts Replacement on page 19.



**Note: Pneumatically actuated devices require clean, pressure regulated, and lubricated air for maximum performance and long life. The most effective and economical way to lubricate Nexen Clutches is with an airline lubricator, which injects oil into the pressurized air, forcing an oil mist into the air chamber.**

Locate the lubricator above and within ten feet of the Clutch, and use a low viscosity oil such as SAE-10.

Synthetic lubricants are not recommended.

Lubricator Drip Rate Settings




**Note: These settings are for Nexen supplied lubricators. If you are not using a Nexen lubricator, calibration must replicate the following procedure.**

- 1) Close and disconnect the air line from the unit.
- 2) Turn the Lubricator Adjustment Knob clockwise three complete turns.
- 3) Open the airline.
- 4) Close the airline to the unit when a drop of oil forms in the Lubricator Sight Gage.
- 5) Connect the airline to the unit.
- 6) Turn the Lubricator Adjustment Knob counterclockwise until closed.
- 7) Turn the Lubricator Adjustment Knob clockwise 1/3 turn.
- 8) Open the airline to the unit.




## Parts Replacement

See Figure 4 on page 19 for all references on this page



- 1) Remove the Retaining Ring (Item 2)
  - 2) Depending on which version of the BW Clutch is being used, remove the Pilot Mount Disc (Item 15) or the Sheave (Item 4).
  - 3) Press the old Bearing (Item 3) out of the Sheave or Pilot Mount Disc.
  - 4) Clean the bearing bore of the Sheave (Item 4) or Pilot Mount Disc (Item 15) with fresh solvent making sure all old Loctite® residue is removed.
  - 5) Apply and adequate amount of Loctite® RC609 to evenly coat the outer race of the new Bearing (Item 3).
  - 6) Carefully align the outer race of the new Bearing (Item 3) with the bore of the Sheave or Pilot Mount Disc and press the new Bearing (Item 3) into place.
  - 7) Remove the first old Spring Retaining Washer (Item 23), old Return Spring (Item 5), and the second old Spring Retaining Washer (Item 23) from the Hub (Item 1).
  - 8) Slide the old Friction Disc Assembly (Item 7) off of the Hub (Item 1).
  - 9) Remove the old Disc Key (Item 6).
  - 10) Slide the Hub (Item 1) out of the Air Chamber (Item 9) and Piston (Item 13).
  - 11) Separate the Piston (Item 13) from the Air Chamber (Item 9).
  - 12) Remove the old O-ring Seal (Item 11) form the Air Chamber (Item 9).
  - 13) Press the old Thrust Bearing (Item 8) out of the Air Chamber (Item 9).
  - 14) Carefully align the outer race of the new Thrust Bearing (Item 8) with the bore of the Air Chamber (Item 9) and press the new Thrust Bearing (Item 8) into place.
  - 15) Remove the old O-ring Seal (Item 10) form the Piston (Item 13).
  - 16) Press the old Thrust Bearing (Item 8) out of the Piston (Item 13).
  - 17) Carefully align the outer race of the new Thrust Bearing (Item 8) with the bore of the Piston (Item 13) and press the new Thrust Bearing (Item 8) into place.
  - 18) Clean the O-ring contact surfaces of the Air Chamber and Piston with fresh safety solvent.
  - 19) Coat the O-ring contact surfaces of the Air Chamber and Piston with fresh O-ring lubricant and wipe off any excess lubricant.
  - 20) Coat the new O-ring Seals (Items 10 and 11) with fresh O-ring Lubricant.
  - 21) Install the new O-ring Seals (Items 10 and 11).
  - 22) Slide the Piston (Item 13) into the Air Chamber (Item 9).
  - 23) Slide the Air Chamber and Piston onto the Hub (Item 1).
  - 24) Install the new Disc Key (Item 6) into the Hub.
  - 25) Slide the new Friction Disc Assembly (Item 7) onto the Hub (Item 1) and Disc Key (Item 6).
- Note: The closed end of the Return Spring (Item 5) must face toward the Retaining Ring (Item 2).**
- 26) Install the new Return Spring (Item 5) and Spring Retaining Washers (Item 23).
  - 27) Press the Pilot Mount Disc (Item 15) and Bearing (Item 3) or the Sheave (Item 4) and Bearing (Item 3) onto the Hub (Item 1).
  - 28) Reinstall the Retaining Ring (Item 2).





1

ITEM	DESCRIPTION	QTY
1	Hub	1
2	Retaining Ring (Ext.)	1
3	Bearing	1
4	Sheave	1
5 <sup>1</sup>	Return Spring	1
6 <sup>1</sup>	Disc Key	1
7 <sup>1</sup>	Friction Disc Assembly	1
8 <sup>1</sup>	Thrust Bearing	2
9	Air Chamber	1
10 <sup>1</sup>	O-Ring Seal (Large)	1
11 <sup>1</sup>	O-Ring Seal (Small)	1
13	Piston	1
14	Washer	1
15	Pilot Disc Mount	1
18	Air Inlet Fitting	1
19	Air Hose Assembly (Not Shown)	1
20	Set Screw (Not Shown)	2
21	Key (Not Shown)	1
23 <sup>1</sup>	Spring Retaining Washer	2

<sup>1</sup> Denotes Repair Kit Item (Repair Kit No. 846800)




# Troubleshooting

<b>Machine doesn't continue to run after the start button is pressed for the second time (after the power on LED is lit).</b>	
	<ol style="list-style-type: none"> <li>1. The thread break detectors are threaded wrong or damaged. (See thread sensor instructions on page 15).</li> <li>2. The fabric sensor is not properly aligned (not looking through the slot) or damaged.</li> <li>3. Left hand head is turned off, but the left hand head thread break sensors are turned on.</li> </ol>
<b>Machine will not stop after fabric runs out</b>	
	<ol style="list-style-type: none"> <li>1. The fabric sensor is not properly aligned (not looking through the slot) or damaged.</li> <li>2. Reflective tape on handwheel is worn or is not at least 1 inch long.</li> <li>3. Motor speed has been decreased and is running slower than 5000 rpm. If this has occurred, call Atlanta Attachment Company for necessary adjustments to correct this problem.</li> </ol>
<b>Sewing heads will not turn on</b>	
	<ol style="list-style-type: none"> <li>1. Check Left head on/off switch on rear of control box.</li> <li>2. Check that all plugs on motor are plugged in securely.</li> </ol>
<b>Heads sewing, but feed rollers not turning</b>	
	<ol style="list-style-type: none"> <li>1. Step motor control box should be turned on (see power light on front of step motor control box).</li> <li>2. Check fuse in stepper motor control box.</li> <li>3. Check belt going from step motor to feed roller.</li> <li>4. Check pulleys on step motor and feed roller (set screws should be tight).</li> <li>5. Thumbwheels on front of step motor control box should have a number value from 150-220.</li> </ol>
<b>Heads sewing, feed rollers turning, but cloth not being pulled through</b>	
	<ol style="list-style-type: none"> <li>1. Check air pressure, should be 30-40 psi. Higher pressures may cause feed rollers to stall.</li> <li>2. Check that feed roller switch is set for feed roller down.</li> <li>3. Check that threads on edge of cloth are not wrapped around roll rod.</li> <li>4. Thumbwheels on front of step motor control box should have a number value from 150-220.</li> </ol>
<b>Cloth runs out from under foot.</b>	
	<ol style="list-style-type: none"> <li>1. Check that foot pressure on both heads is minimal - just enough to keep foot from vibrating. (Note: feed dogs are not used to feed the cloth on the 1961, the feed roller feeds the cloth and both feet just "float" on top of the cloth).</li> <li>2. Check fabric threading through guide assembly: over first bar, under second.</li> </ol>

## Electric Eye Sensor Adjustment

To adjust the sensor, first remove the clear plastic cover from the end of the sensor. There are two adjusting screws under the cover. One is labeled “GAIN” and is used to set the sensitivity of the sensor. The other screw is labeled “DO & LO” and should always be fully clockwise.

With the end of the sensor pointing at the center of the reflective tape, turn the “GAIN” screw counter-clockwise until the red LED indicator is off. Then turn the “GAIN” screw clockwise until the LED indicator comes on. Then turn the “GAIN” screw one full turn clockwise. The LED indicator should be blinking slowly. Cover the eye so that the sensor cannot see the reflective tape and the LED should go off.



## Reflective Tape Maintenance

Use a soft cloth for cleaning.

Do not use chemicals or abrasives to clean it.

Avoid any contact with oils and liquids.

Do not touch the tape with bare fingers.

If tape is dirty or opaque, the eye may not function correctly.

## General Machine Maintenance

- Maintenance should only be performed by trained, qualified personnel. Before performing any maintenance or repair work, switch off the electrical, pneumatic, etc. power to the machine at the main source and secure it with a padlock so that it cannot be switched on again without authorization.
- Always wear proper safety equipment when operating or performing maintenance on any equipment.
- All recommended maintenance is for a single shift schedule, adjust as necessary for a multi-shift operation.
- Equipment should not be used for purposes other than designed or specified.

### Daily (8 -10 hrs. of operation)

- Follow manufacturer’s recommendations and guidelines for operation, maintenance, and lubrication of the sewing head.
- Check for proper oil level and/or flow in the sewing head and other oil filled or lubed equipment, fill as needed. Oil all points as indicated.
- Clean the machine at the end of every shift or as excess materials accumulate.
- Clean lint, waste, etc. from the sewing, looper(s) and needle(s), area as it accumulates, remove or open covers as necessary for access.
- Remove any threads or other material(s) wrapped around or between any moving parts.
- Wipe all photocell lenses with a clean non-abrasive dry cloth.
- Open or remove doors and/or covers and inspect belt(s) for debris or wear and clean or replace as necessary.
- Monitor the air pressure filter/regulator and empty as necessary.
- Investigate and report any unusual noises to the proper personnel.

---

### Weekly (40 hrs. of operation)

- Sharp Cloth/Edge trimming knives are essential and should be sharpened as often as needed, check sharpness once a week and sharpen as necessary.
- Check the sewing head drive belt for proper tightness and wear. Adjust and replace as necessary.
- Inspect photocell reflective tape, i.e. (machine handwheel, etc.) and replace if dirty or worn.
- Inspect pillow blocks and other bearings (conveyors and rotating shafts) and remove thread and debris.
- Inspect all moving parts to ensure smooth operation, lube or clean as necessary.

### Monthly (160 hrs. of operation)

- Inspect pillow blocks and other non-sealed bearings (conveyors and rotating shafts) and apply one shot of recommended grease to each bearing/fitting.
- Refer to the manufacturer's guidelines for oil and oil filter changes and other maintenance pertaining to the sewing head and other OEM equipment.
- Monitor the air pressure filter/regulator and replace the filter as necessary.

## Recommended Spare Parts List

Contact AAC's sales department to order replacement parts.

Phone: 770-963-7369  
 Fax: 770-963-7641  
 Email: sales@atlatt.com  
 Website: [www.atlatt.com](http://www.atlatt.com)

### AAC Part # SP1962EG24 Spare Parts Kit (Standard Cutter)

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	000593-91	Timing Gauge	9	100	SNB27140	Needle
2	6	277000	Upper Cutter	10	1	UM-68D	Stone
3	6	277009	Lower Cutter	11	1	UM-68KH10M	Lower Cutter Jig
4	2	277014A	Spreader	12	1	UM-SKS10	Portable Sharpener
5	2	277034	Lower Looper	13	3	ZZZSR-202	Staples
6	1	277511S70M	Throat Plate	14	1	ZZZSR-20W	Scissors
7	1	FFT18FF100Q	Electric Eye	15	1	ZZZSR-220	Plier
8	1	MM742-27BN	Bulb, 12V				

### AAC Part # SP1962EG24HD1 Spare Parts Kit (Wide 10mm Cutter)

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	000593-91	Timing Gauge	12	1	277511S70M	Throat Plate
2	1	201230CM	Shoe, RH, Mod	13	1	FFT18FF100Q	Electric Eye
3	4	210371	Finger	14	1	MM742-27BN	Bulb, 12V
4	6	277000	Upper Cutter	15	200	SNB27140	Needle
5	4	277004	Needle Guard	16	1	UM-68D10	Stone
6	4	277005	Front Needle Guard	17	1	UM-68KH10M	Lower Cutter Jig
7	6	277009	Lower Cutter	18	1	UM-SKS10	Portable Sharpener
8	4	277014A	Spreader	19	3	ZZZSR-202	Staples
9	4	277034	Lower Looper	20	1	ZZZSR-20W	Scissors
10	1	277378A25	Feed Dog, Diff.	21	1	ZZZSR-220	Plier
11	1	27738025	Feed Dog, Main				

# 1962-LPAR4 Parameter Settings

## Before Programming, Perform a Master Reset of Parameters (See Below)

PARAMETER	RANGE	VALUE	DESCRIPTION
290		0	Mode of operation. MUST SET THIS PARAMETER FIRST!
026	0-5	0	F-026=0 to disable the EB401 selection after power on.
111	400-9900 rpm	5000/6000	Maximum speed when "129" is 0, 1, or 2.
119	1-3	1	Linear acceleration
161	0-1	1=CCW	Motor rotation
240	0-31	6	Machine run blockage with open contact
270	0-5	1	External handwheel sensor configuration.
272	015-9999	1000	Drive ratio between motor pulley and handwheel pulley. If handwheel pulley is smaller than motor pulley, increase this value to slow down sewing head until measured speed matches speed set with parameter 111. (For Yamato and Pegasus, setting should be 1000; for Rimoldi, setting should be 1240)
436		0	Use code "5913". This disables an input that was causing box to reset itself.
401	0	1	Change 401 from 0 to 1 to save all parameters

### Front panel LED's:

- LED 1: Off
- LED 2: Off
- LED 3: Off
- LED 4: Off
- LED 5: Off
- LED 6: Off
- LED 7: Off, Stop at needle down.
- LED 8: On, Stop at needle up.

### Programming Instructions:

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "3112"
3. Press "E" once and "2.0.0." is displayed this is a parameter
4. Proceed to the parameter to be changed and press "E"
5. The value now shows in the screen, adjust to desired value.
6. Press "E" to enter value and continue with parameter setting.
7. Repeat for other parameters, press "P" once when complete.
8. Run sewing head to save parameters before powering down

### To Perform Master Reset of Parameters:

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "5913"
3. Press "E" twice and "093" is displayed.
4. Press "+" once, "094" is displayed.
5. Press "P" to exit programming mode with all default values.

**NOTE: Set sewing speed at 5000 and puller speed to 800 for first 90 days of operation and then increase to 6000 and 1000 if desired.**

# 1962-PPAR4 Parameter Settings

**Before Programming, Perform a Master Reset of Parameters (See Below)**

1961 PARAMETER SETTINGS FOR PULLER MOTOR

PARAMETER	RANGE	VALUE	DESCRIPTION
290		0	Mode of operation. MUST SET THIS PARAMETER FIRST!
026	0-5	0	F-026=0 to disable the EB401 selection after power on.
111	400-9900	800/1000*	Maximum speed when "129" is 0, 1, or 2. **
119	1-3	1	Linear acceleration
153	0-50	35	Braking power at standstill
161	0-1	1-CCW	Motor rotation
161	0-1	0-CW	Motor rotation for worm drive pullers
220	1-55	5	Acceleration
270	0-5	5	No handwheel sensor
272	015-9999	240	Drive ratio for worm drive pullers. (current model) (Older belt drive pullers should be set on 1000) The smaller the number the higher the speed
436		0	Use code "5913". This disables an input that was causing box to reset itself.
401	0	1	Change 401 from 0 to 1 to save all parameters

**Front panel LED's:**

- LED 1: Off
- LED 2: Off
- LED 3: Off
- LED 4: Off
- LED 5: Off
- LED 6: Off
- LED 7: Off, Stop at needle down.
- LED 8: Off

**Programming Instructions:**

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "3112"
3. Press "E" once and "2.0.0." is displayed this is a parameter
4. Proceed to the parameter to be changed and press "E"
5. The value now shows in the screen, adjust to desired value.
6. Press "E" to enter value and continue with parameter setting.
7. Repeat for other parameters, press "P" once when complete.
8. Run sewing head to save parameters before powering down

**To Perform Master Reset of Parameters:**

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "5913"
3. Press "E" twice and "093" is displayed.
4. Press "+" once, "094" is displayed.
5. Press "P" to exit programming mode with all default values.

**\*Set sewing speed at 5000 and puller speed to 800 for first 90 days of operation and then increase to 6000 and 1000 if desired.**

# 1962-RPAR4 Parameter Settings

**Before Programming, Perform a Master Reset of Parameters (See Below)**

PARAMETER	RANGE	VALUE	DESCRIPTION
290		0	Mode of operation. MUST SET THIS PARAMETER FIRST!
026	0-5	0	F-026=0 to disable the EB401 selection after power on.
111	200-9900 rpm	5000/6000	Maximum speed when "129" is 0, 1, or 2.
119	1-3	1	Linear acceleration
161	0-1	0=CW	Motor rotation
270	0-5	1	External handwheel sensor configuration.
272	015-9999	1000	Drive ratio between motor pulley and handwheel pulley. If handwheel pulley is smaller than motor pulley, increase this value to slow down sewing head until measured speed matches speed set with parameter 111. (For Yamato and Pegasus, setting should be 1000; for Rimoldi, setting should be 1240)
436		0	Use code "5913". This disables an input that was causing box to reset itself.
401	0	1	Change 401 from 0 to 1 to save all parameters

**Front panel LED's:**

- LED 1: Off
- LED 2: Off
- LED 3: Off
- LED 4: Off
- LED 5: Off, Stop at needle down.
- LED 6: On, Stop at needle up.
- LED 7: Off
- LED 8: Off

**Programming Instructions:**

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "3121"
3. Press "E" once and "4.0.0." is displayed this is a parameter
4. Proceed to the parameter to be changed and press "E"
5. The value now shows in the screen, adjust to desired value.
6. Press "E" to enter value and continue with parameter setting.
7. Repeat for other parameters, press "P" once when complete.
8. Run sewing head to save parameters before powering down

**To Perform Master Reset of Parameters:**

1. Power on holding down the "P" button till "COD" is displayed.
2. Press ">>" once and enter the number "5913"
3. Press "E" twice and "093" is displayed.
4. Press "+" once, "094" is displayed.
5. Press "P" to exit programming mode with all default values.

**NOTE: Set sewing speed at 5000 and puller speed to 800 for first 90 days of operation and then increase to 6000 and 1000 if desired.**





## Assembly Drawings & Parts Lists

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.



**One-Stop Shopping**  
For Expendable Replacement Parts for AAC & Other Bedding Equipment Suppliers  
Toll Free: **1-866-885-5100**  
[www.atlantapartsdepot.com](http://www.atlantapartsdepot.com) • [sales@atlantapartsdepot.com](mailto:sales@atlantapartsdepot.com)



# 11962EG24EH Auto Border Sew, O&U Head


AAC Drawing Number 9002052 Rev 12

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	2	0411-069B	BRKT, THREAD BREAK DETECT	31	1	33008708	BALL BEARING DISC ASSY
2	2	0411-070	CLAMP, SENSOR BRACKET	32	4	4003-IS3WT2	SENSOR,THREAD BREAK
3	2	1959-112	2 POS THREAD PLATE ASSY	33	2	4059-EXT1	CABLE,18", 6 COND
4	2	1961-152G	COVER,REAR, 0-36"	34	2	4059-EXT2	CABLE,18", 4 COND
5	2	1961-207A	PLATE, END	35	1	784B-2432	PLATE, ALU
6	1	1961-252D	ROD, ROLL, 27" L	36	2	97-2250A	SPACER, THREAD STAND
7	1	1961-252E	ROD,ROLL,38.0L	37	1	FFT18FF100Q	EYE, FIXED FIELD, 4IN
8	1	1961-253A	HUB, UNWIND STAND	38	1	MM40450010	FASTENER,SLIDE LOCK
9	1	1961-255	BRACKET, SENSOR MTG	39	2	MMSLD-ECH	1/2" DIA RUBBER BUMPER
10	1	1961-372E	SLEEVE, REWIND, 36" CAP	40	2	NNE5/16-18	NUT,ELASTIC LOCK,5/16-18
11	1	1961-374A	HANDLE, SLEEVE	41	10	SNB27140	NEEDLE, SIZE 140
12	2	1961-403D	SUPPORT, GUIDE	42	4	SSFC01048	1/4-20 X 3/4 FLAT CAP
13	2	1961-500F	SEWING HEAD ASSEM. RH	43	4	SSFC80016	SCR,FLAT HD,CAP,6-32 X 1/4
14	1	1961-800E	WASTE ASSEMBLY	44	2	SSSC80016	6-32 X 1/4 SOC CAP SC
15	AR	1961-900WD3	DIAGRAM, WIRING	45	6	SSSC98032	10-32X1/2, SOC CAP
16	1	1961-KIT10	BORDER SPLICING ASSY	46	15	SSZS93032	SCREW, SHT.METAL 10 ZIP
17	1	1962-001E	MAIN ASSY,O/U,36" CAP	47	2	TTH32416	HANDLE,THRD,1/4-20X1-1/8
18	1	1962-151C	DOOR,1962,29.5X19.3	48	2	TTH32425	HANDLE,THRDED,5/16-18X3/4
19	1	1962-152	COVER,SIDE,18,24 & 36"	49	2	TTH32429	HANDLE,THRD,5/16-18X2.0
20	1	1962-320G	PREFEED & REWIND ASSY	50	9	WWFS1/4	WASHER,FLAT,SAE,1/4
21	1	1962-350E	ROLLER ASSY,REAR,38"	51	4	WWFS10	WASHER, FLAT, #10, SAE
22	2	1962-353D	ROD, STRAIGHT. SP, 303 SS	52	1	WWL1/4	WASHER,LOCK,1/4
23	1	1962-KIT6	ROLLER ASSEMBLY	53	4	WWL10	WASHER,LOCK,#10
24	AR	1962-LPAR	PARAMETER SETTINGS, LFT	54	4	SSHC01128	1/4-20 X 2 HEX CAP
25	AR	1962-PPAR	PARAMETER SETTINGS P MTR	55	4	WWF5/8	WASHER,FLAT,5/8
26	AR	1962-RPAR	PARAMETER SETTINGS, RT	56	4	SSHC01048	1/4-20 X 3/4 HEX CAP
27	2	2 SPOOL TS	2 SPOOL THREAD STAND	57	10	WWF5/16	WASHER,FLAT,SAE,5/16
28	2	211-038	NUT PLATE, FOLDER MOUNT	58	2	SSHC10112	SCREW,HEX,5/16-18X1-3/4
29	1	26151	TOOL TRAY, 1X3.5X9	59	1	SSHC01112	HEX HEAD BOLT 1/4-20X1.75
30	2	33008226	DISC,10GA,SS,2.25 x 10MM	60	4	SSHC10144	SCREW,HEX,5/16-18X2-1/4

Page 32  
Page 48  
Page 33  
Page 36  
  
Page 42  
Page 45  
  
Page 24  
Page 25  
Page 26

Page 46

From the library of: Diamond Needle Corp




From the library of: Diamond Needle Corp

## 1961-500F Sewing Head Assembly

AAC Drawing Number 9001620 Rev 2

NO.	QTY	PART #	DESCRIPTION
1	AR	1961-411	FOOT, R.H., MODIFIED
2	AR	1961-419HD4	PLATE, NEEDLE, MOD HD 4 R
3	1	1962-424	EYE MOUNT, POS. 1 SENSOR
4	1	1975-412A	PLATE,NUT,4-40,.95CTC
5	1	311-128	HUB, HANDWHEEL, TAPE MOUN
6	1	311-129	SLEEVE TAPE MOUNT ADJUST
7	1	FFSM312LVQ	EYE,ELECTRIC,10-30VDC
8	1	spegex5203h	SEW HEAD,ST,NDL,DIFF,5MM
9	2	SSPS70048	4-40 X 3/4 PAN HD SLOTTED
10	2	SSSCM6X15	M6X15 SOC CAP SCREW
11	2	WWFS1/4	WASHER,FLAT,SAE,1/4
12	2	WWL1/4	WASHER,LOCK,1/4




From the library of: Diamond Needle Corp

## 1961-800E Waste Assembly

AAC Drawing Number 9002005 Rev 2


NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	2	1961-802	ADAPTER, 2" PVC TO	11	8	MM5415K19	CLAMP, HOSE, WORM TYPE 1-9/
2	6	1961-803	CHANNEL, TUBE CLAMP	12	2	MM610364	ADAPTOR, 2" PVC THR.M.
3	2	1961-809	PIPE SEGMENT, 2" ID	13	2	MM655462	RING, 2" THREADED LOCK
4	2	1961-817	VENTURI ASSY, 2"	14	*10.7'	MMFH200	HOSE, FLEX 2" ID
5	1	1961-818A	BRACKET, MOUNT, RIGHT	15	1	MMTC32GTAN	CONTAINER, WASTE
6	1	1961-819	BRACKET, MOUNT, LEFT	16	1	MMVLR-11T	FUNNEL, WASTE REMOVAL
7	4	26282A	FILTER HOLDER	17	8	NNK8-32	NUT, KEP, 8-32
8	2	26285A	FILTER, WASTE SYSTEM	18	8	SSPS90024	#8-32 X 3/8 LG PAN HD
9	1	MM00251	FUNNEL, WASTE	19	10	SSPS98024	10-32X3/8 PAN HD SLOT
10	2	MM189472	ELBOW, 2" SCH 40 PVC	20	10	WWL10	WASHER, LOCK, #10



## 1961-KIT10 Border Splicing Assembly

AAC Drawing Number 9002027 Rev 7

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	1278-6161	FOOT SWITCH MODIFICATION	16	2	MMSLD-ECH	1/2" DIA RUBBER BUMPER
2	1	1961-005	BASE, MNT, BAG CLOSER	17	4	NNK1/4-20	NUT, HEX, KEP, 1/4-20, W/LOCK
3	1	1961-008	RISER, BAG CLOSER	18	10	SNDX1X25	NEEDLE
4	1	1961-014	MTG BRKT, BAG CLOSER	19	2	SSFC80016	SCR, FLAT HD, CAP, 6-32 X 1/4
5	1	1961171	PEDAL MOUNT PLATE, W/GUARD	20	2	SSFCM6X20	M6 X 20 FLAT ALLEN
6	6	AAF3/16	CLAMP, BLACK PLASTIC	21	5	SSHC01048	1/4-20 X 3/4 HEX CAP
7	1	BC-1	BORDER CLOSER MACHINE	22	2	SSHC01096	1/4-20 X 1-1/2 HHCS
8	1	BC-1LAB	LABEL	23	2	SSHC01112	HEX HEAD BOLT 1/4-20X1.75
9	6	EE18-2	BLACK TWO COND. CABLE	24	2	SSHC01160	1/4-20 X 2-1/2 HHCS
10	12	EE6X752	TIE WRAP - Small.	25	2	SSZS93032	SCREW, SHT. METAL 10 ZIP
11	8	FF19509	CABLE, 3 COND, 18 AWG, SJTOW	26	2	TTAA5267	TERMINAL, FE, INS, 18-22
12	3	FF31F1022	PIN, MALE .093	27	1	W1061-3	NUT, WIRE
13	3	FF31F1023	PIN, FEMALE .093	28	14	WWFS1/4	WASHER, FLAT, SAE, 1/4
14	1	FF59F1798	CONNECTOR, FEMALE, 3 PIN	29	7	WWL1/4	WASHER, LOCK, 1/4
15	1	FF59F1803	3 PIN MALE CONN				




From the library of: Diamond Needle Corp

## 1962-210A Tension Rack Assembly, 36"

AAC Drawing Number 9002042 Rev 2

NO.	QTY	PART #	DESCRIPTION
1	2	1961-207	PLATE, END
2	2	1961-211	PLATE, EDGE GUIDE
3	2	1962-206A	ROD, MATERIAL TENSION,42"
4	1	1962-403	SUPPORT, GUIDE
5	1	1962-403B	SUPPORT, GUIDE, LONG
6	2	SSAS024064	SHULDER BOLT 3/8 X .1.00L
7	2	SSHC10048	5/16-18 X 3/4 HHCS
8	4	TTH32415	HANDLE, THREADED, 1/4-20X7/
9	2	WWSI5/16	WASHER, INTERNAL TOOTH, 5/16





From the library of: Diamond Needle Corp




# 1962-001E Main Assembly, O/U, 36" Cap

AAC Drawing Number 9002051 Rev 10

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	4	0211-209	PLATE,NUT,10-32@2.25 CTC	36	2	EE24F163	FOOTSWITCH, TREADLITE
2	2	0211-702A	CABLE,POS. SENSOR,6'	37	1	EE37F3311	CEE POWER CORD, 6'
3	1	0211-703A	CABLE,SYNC. ONLY	38	*3.5'	EEDC15X15	DUCT,WIRE COVER,1.5
4	1	0211-705H	CABLE,TREADLE,EXTENSION	39	*3.5'	EEDE15X15	DUCT,WIRE,1.5X1.5
5	8	1100321B	MOUNT,ISOLATOR	40	1	FFRK44T-4	CABLE,EYE,12',NO END
6	1	1278-1095	KIT,AAC,BLOW GUN & LIGHT	41	3	MM132-1202	END CAP,SQUARE,BLACK
7	1	1961-101B	BRKT, HEAD ADJ SCREW	42	1	MM1910A23M	RULER,SILVER MYLAR 36"
8	1	1961-111E	SUPPORT,PULLER,HEAVY DUTY	43	4	MM427-3RB	CASTER,SWIVEL,3"RUBBER
9	4	1961-115	LEG WELDMENT	44	4	NNH1/4-20	NUT,HEX,1/4-20
10	1	1961-121E	SUPPORT,PULLER	45	19	NNK1/4-20	NUT,HEX,KEP,1/4-20,W/LOCK
11	2	1961-159	PLATE, MOUNT, FOOT PEDAL	46	1	PPM6245K116	PULLEY,V,3.0 OD,
Page 38	12	1961-300GB	PULLER ASSY,36"WORM GEAR	47	1	PPM6245K414	PULLEY,V,2.0 OD,
13	2	1961-401	RAIL,GUIDE	48	4	SSFC80016	SCR,FLAT HD,CAP,6-32 X 1/4
14	1	1961-409B	PLATE, MOUNT, RIGHT HEAD	49	4	SSHCO1032	1/4-20 X 1/2 HHCS
15	1	1961-410B	POINTER,SERGE WIDTH	50	16	SSHCO1040	1/4-20 X 5/8 HHCS
16	1	1961-412A	BLOCK,INDEX,LEFT HEAD	51	14	SSHCO1048	1/4-20 X 3/4 HEX CAP
17	2	1961-421	MT,MOTOR,EFKA	52	2	SSHCO1056	1/4-20 X 7/8 HEX CAP
Page 40	18	1961-900D	CONTROL BOX	53	4	SSHCO1096	1/4-20 X 1-1/2 HHCS
Page 48	19	*AR 1961-900WD3	DIAGRAM, WIRING	54	12	SSHCO1112	HEX HEAD BOLT 1/4-20X1.75
20	1	1961-903A	COVER, ELECTRICAL PANEL	55	4	SSHCO1160	1/4-20 X 2-1/2 HHCS
21	4.5'	1961-BELT	V-BELT,3/8 X 50.5"	56	4	SSPS98024	10-32X3/8 PAN HD SLOT
22	*AR	1961LAB3	LABEL	57	7	SSSC01048	1/4-20 X 3/4" SOC CAP SC
Page 47	23	*AR 1961PD1	DIAGRAM, PNEUMATIC	58	6	SSSC80016	6-32 X 1/4 SOC CAP SC
24	1	1962-100E	FRAME,AUTO-BORDER, O/U,36	59	23	SSSC98032	10-32X1/2, SOC CAP
25	2	1962-122A	MNT,MOTOR CONTROL, TRIPLE	60	8	SSSC98048	10-32 X 3/4 SOC CAP
Page 34	26	1962-210A	TENSION RACK ASSY, 36"	61	8	SSZS93032	SCREW, SHT.METAL 10 ZIP
27	1	1962-406	SCREW, HEAD LOCATION ADJ.	62	2	UUFF520-10	BRG,BRONZE,.3765ID
28	1	1962-409	PLATE, MT, LH, PEG EX5203	63	2	UUFF723-05	BEARING,BRONZE,.505ID
29	2	4003-MA3/FE	CABLE,8 FT,3 FEM	64	68	WWFS1/4	WASHER,FLAT,SAE,1/4
30	2	4059-DC1500	MOTOR,DC WITH CONTROLLER	65	37	WWFS10	WASHER, FLAT, #10, SAE
31	1	4120-001	ROD, STRAIGHT. SP, 1018	66	42	WWL1/4	WASHER,LOCK,1/4
32	1	951A-0844	CRANK HANDLE, MODIFIED	67	31	WWL10	WASHER,LOCK,#10
33	2	AAF3/16	CLAMP, BLACK PLASTIC	68	6	WWL6	WASHER,LOCK,#6
34	1	AP-28-812	CABLE,STEP MOTOR	69	2	ZX3827	V-BELT,3/8 X 27"
35	2	CCCL6F	CLAMP COLLAR- 3/8				

From the library of: Diamond Needle Corp




# 1961-300GB Puller Assembly, 36" Worm Gear

AAC Drawing Number 9000849 Rev 2

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	2	0211-209	PLATE,NUT,10-32@2.25 CTC	31	2	AAC7DP-1	CYL.,AIR,DA 3/4 BORE,1STR
2	1	1961-302	PLATE,LEFT SIDE,PULLER	32	2	AAFBP-11C	BRKT,PIVOT,1/4 BORE
3	1	1961-303	PLATE,RIGHT SIDE,PULLER	33	2	AAFCT-7	CLEVIS,AIR CYL, 1/4-28
4	1	1961-304	HINGE PLATE,PULLER	34	4	AAQME-5-8	QUICK MALE ELBOW
5	1	1961-305	TOP,LEFT SIDE,PULLER	35	4	BB1L005	BEARING,BALL, .500D
6	1	1961-306	TOP,RIGHT SIDE,PULLER	36	1	GG124L050	BELT, 3/8P,, 1/2W
7	1	1961-307E	PLATE, TOP, PULLER	37	1	MM1910A23M	RULER,SILVER MYLAR 36"
8	1	1961-309E	GUARD,ROLLER,36" CAPACITY	38	1	MM20U1-30M1	WORM, REDUCE,30:1,RH
9	1	1961-311E	ROD,STRIAGHT,CRS,1/2X	39	1	MMMD35 (18.75" LG)	CHAIN,STEEL, DBL #35-2 X 32IN LG
10	1	1961-312A	BRKT,LIFT,LEFT	40	1	MMMD35CL	MASTER LINK,DBL,#35 CHAIN
11	1	1961-313E	PLATE, BASE, PULLER	41	1	PP14LF050M1	PULLEY, 3/8P, 14T, 5/8B
12	1	1961-314	HINGE PLATE, WORM PULLER	42	1	PP14LF050M2	PULLEY, 3/8P, 14T, 14MM B
13	1	1961-315A	BRKT,LIFT	43	2	SSFC01024	1/4-20 X 3/8 FLAT CAP
14	1	1961-316E	BOTTOM,GUARD,36" CAPACITY	44	4	SSHC01048	1/4-20 X 3/4 HEX CAP
15	1	1961-323	SPACER, ALUM, 1/4	45	8	SSHC10048	5/16-18 X 3/4 HHCS
16	1	1961-363E	GUARD, TOP	46	4	SSHC98032	10-32X1/2 HEX HD
17	1	1961-371E	GUARD,ROLLER,36" CAPACITY	47	4	SSSC01032	1/4-20X1/2 SOC CAP
18	1	1961022	MTG. PLT, EFKA MOTOR	48	2	SSSC01048	1/4-20 X 3/4" SOC CAP SC
19	1	1961024	GUARD, WORM DRIVE	49	4	SSSC01064	1/4-20 X 1 SOC CAP
20	1	1961025	GUARD, EFKA MOTOR	50	2	SSSC90032	#8-32 X 1/2 SOC CAP SC
21	1	1961027	PLATE,MNT,WORM DRIVE	51	17	SSSC98032	10-32X1/2, SOC CAP
22	2	1961028	KEY, 3/16 SQ X 11/16 LG	52	4	SSSC98040	10-32 X 5/8 SOC CAP
23	1	1961058	COVER, ROLLER DRIVE BELT	53	2	WWF8	WASHER, FLAT, #8
24	1	1961100	SPROCKET, 12T, 35, DBL, M	54	8	WWFS1/4	WASHER,FLAT,SAE,1/4
25	1	1961101	SPROCKET, 30T, 35, DBL,	55	21	WWFS10	WASHER, FLAT, #10, SAE
26	1	33005603E	PULLER, ROLLER, 36" CAP.	56	8	WWFS5/16	WASHER,FLAT,SAE,5/16
27	1	3.30E+09	SHAFT, PREFEED DRIVE, 36"	57	8	WWL1/4	WASHER,LOCK,1/4
28	1	33005652E	PULLER, ROLLER, 24" CAP	58	21	WWL10	WASHER,LOCK,#10
29	1	3.30E+10	SHAFT, PREFEED IDLER	59	8	WWL5/16	WASHER, LOCK, 5/16
30	1	4059-DC1500	MOTOR & CONTROLLER				

From the library of: Diamond Needle Corp



**PROGRAMMING THE HOUR METER:**  
 Enable the front keypad with the DIP switch #3. Press SEL.  
 The current range will be displayed. Press the RST button  
 until "88888888" is displayed. Press the SEL button.  
 Disable the front keypad with the DIP switch #3


# 1961-900D Control Box

AAC Drawing Number 9001726 Rev 2

Page 48

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	0211-703B	CABLE, LEFT CONTROL BOX	33	1	EECA491024	CONTACTOR, MINI, 240V
2	1	0211-705B	CABLE, TREADLE	34	1	EEPF3	BUTTON, PUSH 22MM, GREEN MO
3	1	0411-1950C	CABLE, LAMP AMBER 24 V	35	1	EEPF4	BUTTON, PUSH 22MM, RED
4	1	0411-1950D	CABLE, LAMP RED 24 V	36	1	EEPMTS44	E-STOP BUTTON, TWIST REL.
5	AR	1961-900WD3	DIAGRAM, WIRING	37	7	FF1724	STRAIN RELIEF
6	1	1961-904B	MOUNT, REGULATORS	38	1	FF1N4007	DIODE
7	1	1961-909A	CABLE, FOOT PRDAL	39	10	FF264-341	TERMBLK,WAGO, TOP, DUAL, GRY
8	1	1961-912A	CONTROL PANEL	40	3	FF264-347	TERMBLK,WAGO, TOP, DUAL, GRN
9	1	1961-913A	SUB PANEL	41	4	FF264-371	TERMBLK,WAGO, TOP, END
10	1	1961-914A	CABLE, RELAY	42	1	FF3120L420A	CIRCUIT BREAKER, THERMAL
11	AR	1961LAB3	LABEL	43	2	FF34576Q	SW, TOGGLE DPDT 20A
12	AR	1961PD1	DIAGRAM, PNEUMATIC	44	8	FF67F4078	SPACER, THREADED 3/8 L
13	1	31103701	BRKT,PRESSURE GAUGE	45	1	FF79998861	HOUR METER, 8 DIGIT LCD
14	1	40-322	BOTTOM, AC POWER LOCKOUT	46	1	FF81F4591	FASTON, PIGGY BACK, 1/4"
15	1	40-323	TOP, AC POWER LOCKOUT	47	1	FFD2425F	RELAY, SSR, 24VAC, 25A
16	1	4000D-02	PC BOARD, RELAY	48	1	FFRAV781BW	MODULE, TVS, 240 VAC
17	1	AA198-503	0-30PSI AIR GAGE 1/8NPT	49	2	MM4554K11	PLUG, 1/8" PIPE
18	1	AA198-5102	REGULATOR W/GAUGE & NUT	50	2	MM4X641	1/8" RIVET ALUM
19	1	AA198-RP3	REGULATOR, PRECISION AIR	51	1	MM9280K33	GROMMET, FLANGE, 1.03 ID
20	2	AA2001F-03	FLOW CONTROL, INLINE, 5/32	52	1	NNH8-32	HEX-NUT 8-32 REG.
21	1	AAE711C24D	AIR VALVE	53	16	SSPP80016	#6-32X1/4 PAN PHILLIPS
22	1	AAF10289	T-FITTING 1/4" NPT	54	2	SSPP80024	#6-32X3/8 PAN PHILLIPS
23	1	AAQMC-5-8	QU. MALE CONN 5/32X1/8	55	3	SSPP90024	8-32X3/8 PAN PHLPS
24	1	AAQME-4-4	ELBOW, MALE, 1/4X1/4NPT	56	2	SSPP98024	10-32 X 3/8 PAN HD PHILIP
25	2	AAQME-4-8	ELBOW, QUICK MALE, 1/4X1/8	57	2	SSSC01128	1/4-20 X 2 SOC CAP
26	1	AAQME-5-4	ELBOW, MALE 5/32X1/4NPT	58	7	TT1825	FEMALE, QUICK SLIDE
27	4	AAQME-5-8	QUICK MALE ELBOW	59	19	TT1825-1	FEMALE, QUICK SLIDE
28	2	AAQUT-5-5	UNION TEE 5/32	60	1	TT5811	TERMINAL, RING, #10 STUD
29	1	AAV41V	VALVE, TOGGLE	61	2	WWFS1/4	WASHER, FLAT, SAE, 1/4
30	2	EE3X01	BLOCK, P.B. CONTACT, N.C.	62	2	WWFS10	WASHER, FLAT, #10, SAE
31	3	EE3X10	BLOCK, P.B. CONTACT, N.O.	63	2	WWSI8	WASHER, INT. TOOTH, 8
32	3	EEA3L	LATCH, PUSH BUTTON				

From the library of: Diamond Needle Corp



# 1962-320G Prefeed & Rewind Assembly

AAC Drawing Number 9001954 Rev 8



NO.	QTY	PART #	DESCRIPTION
1	1	26238	LEG SUB-ASSEMBLY
2	2	1334326	MOUNT, FLANGE
3	1	1334375	DISC, REWIND, 24 X 32
4	1	1334387	CATCH, MATL. TAKEUP REEL
5	1	1334388	HUB, TAKEUP SPINDLE
6	1	1961-251C	HUB UNWIND SHAFT
7	2	1961-319	PLATE,NUT,3/8-16@3.00 CTC
8	1	1961-331	MOUNT, MOTOR
9	1	1961-332	COVER, MOTOR
10	1	1961-379	SUPPORT,REWIND SLEEVE
11	1	1961104	COVER, INSPECTION
12	1	1962-321A	FRAME, PREFEED & REWIND
13	1	1962-330G	CLUTCH ASSY,GENERIC
14	1	GG225L075	BELT, 3/8P, 60T, 3/4W
15	1	K-235A	CONNECTOR,ROMEX,3/4"
16	4	MM132-1496	PLUG 1 X 2
17	1	MMBH2LM22R	MOTOR,GEAR,R/A,220V
18	4	NNH3/8-16	NUT,HEX,3/8-16
19	1	PP22LB075-1-1/8	PULLEY, GEAR, 3/8P, 22T
20	2	WWF8	WASHER, FLAT, #8
21	4	SSFC98032	10-32 X 1/2 FLAT ALLEN CAP
22	2	SSPP90024	8-32X3/8 PAN PHLPS
23	4	SSHC01096	1/4-20 X 1-1/2 HHCS
24	4	SSHC25096	3/8-16 X 1 1/2 HEX HEAD
25	4	SSHC01160	1/4-20 X 2-1/2 HHCS
26	4	SSPP98032	10-32 X 1/2 PAN PHIL
27	6	SSFC80024	6-32 X 3/8 FLAT CAP
28	4	SSHC25128	3/8-16 X 2 HEX CAP
29	2	SSHC01048	1/4-20 X 3/4 HEX CAP
30	4	SSPS95024	#10-24 X 1/4 PAN HD SLTD
31	2	SSSC01064	1/4-20 X 1 SOC CAP
32	4	SSHC01112	HEX HEAD BOLT 1/4-20X1.75
33	14	WWFS1/4	WASHER,FLAT,SAE,1/4
34	4	WWFS10	WASHER, FLAT, #10, SAE
35	12	WWFS3/8	WASHER,FLAT,SAE,3/8
36	14	WWL1/4	WASHER,LOCK,1/4
37	4	WWL10	WASHER,LOCK,#10
38	8	WWL3/8	WASHER, LOCK, 3/8
39	2	WWL8	WASHER,LOCK,#8

Page 43

Page 44

From the library of: Diamond Needle Corp






From the library of: Diamond Needle Corp

## 26238 Leg Sub-Assembly

AAC Drawing Number 9001599 Rev 1

NO.	QTY	PART #	DESCRIPTION
1	1	26127	LEG FOR AP-26-02
2	1	MMFB4444	FOOT, RUBBER






## 1962-330G Generic Clutch Assembly

AAC Drawing Number 9001953 Rev 2

NO.	QTY	PART #	DESCRIPTION
1	1	1961-321	PLATE, ADAPTOR, AIR CLUTC
2	1	1961-354B	SUPPORT, AIR CLUTCH
3	1	1961-365B	BLOCK, BEARING MOUNT
4	1	1961-366A	PULLEY,CLUTCH,22 TH,3/8 P
5	1	1962-375	SHAFT, AIR CLUTCH, MM8028
6	1	AAQMEL-5-8	QUICK MALE ELBOW, LONG
7	2	BBS8703-88	BEARING,BALL,.75IDX1.75OD
8	1	MM802860	CLUTCH,AIR,3/4 BORE,4.5"D
9	1	MM9600K21	GROMMET,RUBBER,9/16 ID
10	4	SSSC01096	1/4-20 X 1-1/2 SOC CAP
11	3	SSSC90064	#8-32 X 1 SOC CAP
12	2	SSSC98032	#10-32 X 1/2 SOC CAP
13	2	SSSS01016	1/4-20 X 1/4 KNURL PT
14	2	WWFS10	WASHER, FLAT #10
15	2	WWL10	#10 LW




From the library of: Diamond Needle Corp

## 1962-350E Rear Roller Assembly, 38"

AAC Drawing Number 9002038 Rev 2

NO.	QTY	PART #	DESCRIPTION
1	2	1335-813E	DISC,BEVEL EDGE,CLAMPING
2	1	1962-351	BRKT, LEFT, REAR ROLLER
3	1	1962-352	BRKT, RIGHT, REAR ROLLER
4	2	1962-353E	ROD,STRA,SP,3/4 X 64.06L
5	2	1962-354E	ROLLER, SINGLE FLANGE
6	4	CCCL12F	CLAMP COLLAR- 3/4
7	4	SSFC01048	1/4-20 X 3/4 FLAT CAP




## 33008708 Ball Bearing Disc Assembly

AAC Drawing Number 9000904 Rev 4

NO.	QTY	PART #	DESCRIPTION
1	1	33008604	CONE, SPOOL
2	1	33008602	HUB, FLANGE 3/4 BORE
3	1	SEE CHART	SEE CHART
4	1	33008601	HUB, CENTER, 3/4 SHAFT
5	1	BB23216-88	BEARING, BALL, 1.0B
6	1	RRLC026B1	SPRING, COMP .026X.18X.25
7	1	JJ012	3/16 DIA. BALL
8	1	SSSP01016	1/4-20 X 1/4 NYLOCK
9	1	SSW#1_4	WING SCREW KNOB
10	1	SSSC01064	1/4-20 X 1 SOC CAP
11	2	SSFS80016	6-32 X 1/4, FLAT SLOT

-	BALL BEARING	DISC ASSEMBLY	33008732
3	1	33008632	DISC 32" DIA
-	BALL BEARING	DISC ASSEMBLY	33008724
3	1	33008624	DISC 24" DIA
-	BALL BEARING	DISC ASSEMBLY	33008716
3	1	33008616	DISC 16" DIA
-	BALL BEARING	DISC ASSEMBLY	33008708

# 1961PD1 Pneumatic Diagram



From the library of: Diamond Needle Corp



# Atlanta Attachment Company (AAC) Statement of Warranty

## Manufactured Products

Atlanta Attachment Company warrants manufactured products to be free from defects in material and workmanship for a period of eight hundred (800) hours of operation or one hundred (100) days whichever comes first. Atlanta Attachment Company warrants all electrical components of the Serial Bus System to be free from defects in material or workmanship for a period of thirty six (36) months.

## Terms and Conditions:

- AAC Limited Warranty becomes effective on the date of shipment.
- AAC Warranty claims may be made by telephone, letter, fax or e-mail. All verbal claims must be confirmed in writing.
- AAC reserves the right to require the return of all claimed defective parts with a completed warranty claim form.
- AAC will, at its option, repair or replace the defective machine and parts upon return to AAC.
- AAC reserves the right to make the final decision on all warranty coverage questions.
- AAC warranty periods as stated are for eight hundred (800) hours or one hundred (100) days whichever comes first.
- AAC guarantees satisfactory operation of the machines on the basis of generally accepted industry standards, contingent upon proper application, installation and maintenance.
- AAC Limited Warranty may not be changed or modified and is not subject to any other warranty expressed or implied by any other agent, dealer, or distributor unless approved in writing by AAC in advance of any claim being filed.

## What Is Covered

- Electrical components that are not included within the Serial Bus System that fail due to defects in material or workmanship, which are manufactured by AAC are covered for a period of eight hundred (800) hours.
- Mechanical parts or components that fail due to defects in material or workmanship, which are manufactured by AAC.
- Purchased items (sewing heads, motors, etc.) will be covered by the manufacturers (OEM) warranty.
- AAC will assist in the procurement and handling of the manufacturers (OEM) claim.

## What Is Not Covered

- Parts that fail due to improper usage, lack of proper maintenance, lubrication and/or modification.
- Damages caused by; improper freight handling, accidents, fire and issues resulting from unauthorized service and/or personnel, improper electrical, plumbing connections.
- Normal wear of machine and parts such as Conveyor belts, "O" rings, gauge parts, cutters, needles, etc.
- Machine adjustments related to sewing applications and/or general machine operation.
- Charges for field service.
- Loss of time, potential revenue, and/or profits.
- Personal injury and/or property damage resulting from the operation of this equipment.

# Declaración de Garantía

## Productos Manufacturados

Atlanta Attachment Company garantiza que los productos de fabricación son libres de defectos de material y de mano de obra durante un periodo de ochocientos (800) horas de operación o cien (100) días cual llegue primero. Atlanta Attachment Company garantiza que todos los componentes del Serial bus son libres de defectos de material y de mano de obra durante un periodo de treinta y seis (36) meses.

## Términos y Condiciones:

- La Garantía Limitada de AAC entra en efecto el día de transporte.
- Reclamos de la Garantía de AAC pueden ser realizados por teléfono, carta, fax o correo electrónico. Todo reclamo verbal tiene que ser confirmado vía escrito.
- AAC reserva el derecho para exigir el retorno de cada pieza defectuosa con un formulario de reclamo de garantía.
- AAC va, según su criterio, reparar o reemplazar las máquinas o piezas defectuosas devueltas para AAC.
- AAC reserva el derecho para tomar la decisión final sobre toda cuestión de garantía.
- Las garantías de AAC tiene una validez de ochocientas (800) horas o cien (100) días cual llega primero.
- AAC garantiza la operación satisfactoria de sus máquinas en base de las normas aceptadas de la industria siempre y cuando se instale use y mantenga de forma apropiada.
- La garantía de AAC no puede ser cambiado o modificado y no está sujeto a cualquier otra garantía implicado por otro agente o distribuidor menos al menos que sea autorizado por AAC antes de cualquier reclamo.

## Lo Que Está Garantizado

- Componentes eléctricos que no están incluidos dentro del sistema Serial Bus que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes mecánicos que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes comprados (Motores, Cabezales, ) son protegidos debajo de la garantía del fabricante.
- AAC asistirá con el manejo de todo reclamo de garantía bajo la garantía del fabricante.

## Lo Que No Está Garantizado

- Falla de repuestos al raíz de uso incorrecto, falta de mantenimiento, lubricación o modificación.
- Daños ocurridos a raíz de mal transporte, accidentes, incendios o cualquier daño como resultado de servicio por personas no autorizados o instalaciones incorrectas de conexiones eléctricas o neumáticas.
- Desgaste normal de piezas como correas, anillos de goma, cuchillas, agujas, etc.
- Ajustes de la máquina en relación a las aplicaciones de costura y/o la operación en general de la máquina.
- Gastos de Reparaciones fuera de las instalaciones de AAC
- Pérdida de tiempo, ingresos potenciales, y/o ganancias.
- Daños personales y/o daños a la propiedad como resultado de la operación de este equipo.



**Atlanta Attachment Company**  
362 Industrial Park Drive  
Lawrenceville, GA 30046  
770-963-7369  
[www.atlatt.com](http://www.atlatt.com)

**Printed in the USA**

From the library of: Diamond Needle Corp