

AAC Part # SP1961EG24 Spare Parts Kit (Standard Cutter)

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	541	Timing Gauge	12	1	2775045R50M	Throat Plate, RH
2	1	000593-91	Timing Gauge	13	1	FFT18FF100Q	Electric Eye
3	4	201121A	Upper Cutter	14	1	MM742-27BN	Bulb, 12V
4	6	202295	Lower Cutter	15	100	SNB27140	Needle
5	4	205607	Upper Cutter	16	1	UM68D	Stone
6	6	205609	Lower Cutter	17	1	UM-68KH10	Cutter Holder
7	2	211161	Lower Looper	18	1	UM-SKS10	Portable Sharpener
8	2	211156	Upper Spreader	19	3	ZZZSR-202	Staples
9	1	211726M	Throat Plate, LH	20	1	ZZZSR-20W	Scissors
10	2	277014A	Spreader	21	1	ZZZSR-220	Plier
11	2	277034	Lower Looper				

AAC Part # SP1961EG24HD1 Spare Parts Kit (Wide 10mm Cutter)

NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	000541	Timing Gauge	17	6	277009	Lower Cutter, Wide
2	1	000593-91	Timing Gauge	18	2	277014A	Spreader
3	6	1961-002	Lower Cutter, LH, Wide	19	2	277034	Lower Looper
4	4	1961-003	Upper Cutter, LH, Wide	20	1	277378A25-G	Feed Dog, Main
5	1	201230CM	Shoe, RH, Mod	21	1	27738025-G	Feed Dog, Diff
6	2	211146	Needle Guard, Front	22	1	277511S70M	Throat Plate, Wide Cutter
7	2	211161	Lower Looper	23	1	FFT18FF100Q	Electric Eye
8	2	211156	Upper Spreader	24	1	MM742-27BN	Bulb, 12V
9	2	211621	Needle Guard, Rear	25	100	SNB27140	Needle
10	1	211726M1	Needle Plate, LH	26	1	UM-68D10	Stone
11	1	211735	Feed Dog, Main	27	1	UM-68KH10	Cutter Holder
12	1	211738	Feed Dog, Diff.	28	1	UM-SKS10	Portable Sharpener
13	1	211744M	Shoe, LH, Mod	29	3	ZZZSR-202	Staples
14	4	277000	Upper Cutter, Wide	30	1	ZZZSR-20W	Scissors
15	2	277004	Needle Guard	31	1	ZZZSR-220	Plier
16	2	277005	Needle Guard, Front				